



Detox Yoghurt Mask

1703B-DYM

Thanks to our latest microalgae extract, this milky jelly mask deeply protects your skin from pollution (external or in house pollution). To benefit from all the power of our **Natura-Tec Marine CellShield AP**, no need to rinse the mask, just remove the excess of formula with a cotton pad after few minutes.

Ingredients	INCI	%	Function
Phase 1			
Deionized Water	Aqua (Water)	70,50	Solvent
Natura-Tec Glycerin – Organic	Glycerin	10,00	Humectant
Natura-Tec Rice Starch	Oryza Sativa (Rice) Starch	4,00	Rheology modifier
Amaze XT (Akzonobel)	Dehydroxanthan Gum	0,30	Rheology modifier
Phase 2			
Natura-Tec Crystal Cream	Sucrose Polystearate (and) Cetearyl Alcohol (and) Olea Europaea (Olive) Oil Unsaponifiables	5,00	O/W emulsifier
Natura-Tec Abysoft	Crambe Abyssinica Seed Oil Phytosterol Esters	5,00	Cosmos skin conditioner
Phase 3			
Natura-Tec Rice Starch	Oryza Sativa (Rice) Starch	2,00	Sensorial agent
Natura-Tec Marine CellShield AP	Caprylic/Capric Triglyceride (and) Pavlova Lutheri Extract	2,00	Anti-Pollution Active
C39-6393 Suncroma FD&C Blue 1	CI 42090	Qsp	Dye
Mandarin essential oil	Citrus Reticulata Peel Oil	0,20	Essential Oil / Perfume
Geogard ECT (Lonza)	Benzyl Alcohol (and) Salicylic Acid (and) Glycerin (and) Sorbic Acid	0,80	Preservative
Phase 4			
Sodium Hydroxide (25% sol)	Sodium Hydroxide	0,05	pH adjuster

Appearance: Extremely light and fresh green jellified emulsion.
pH= 5,3 - Viscosity (20°C): 87 000 mPa.s (LV4; 5 rpm)

Procedure :

Heat to 75 °C separately phase 1 and 2. At temperature, add phase 2 to 1 whilst stirring moderately. Homogenize using Ultra Turrax (2 min at 6000 rpm). Allow to cool down whilst stirring moderately. Add phase 3 below 40°C. Adjust pH with phase 4.

Way of use: Apply a thick layer on the skin. Let the actives penetrates for few minutes. Remover with a cotton pad or let during the night.