

Sun Protect & Repair Solid Cream in Stick



2508B—SPRSC

As the days get sweeter and the colors warmer, it's time to adopt a beauty routine that captures the spirit of this unique time. Combining sustainable, natural and efficient ingredients, this formula contains everything you need to nourish, and protect your skin in a world where taking care of yourself goes hand in hand with taking care of the planet.

Based on Plantsil XLite, our ultralight alternative to silicone and Natural BBB, our multifunctional ready to use balm base it delivers a unique sensation of lightness and smoothness leaving a delicate veil on the skin insuring sun protection, nutrition while boosting skin natural protection against environmental aggressions thanks to our microalgae active, Natura-Tec SeaBerry Blue.



	Ingredients	INCI	%	Function
A	Natural BBB – Beauty Balm Base	Hydrogenated Ethylhexyl Olivatate (and) Hydrogenated Castor Oil (and) Butyrospermum Parkii Butter (and) Tocopherol	28,50	Ready to use texturizing natural balm base.
	Natural Sunflower SeedWax	Heliantus Annuus (Sunflower) Seed Wax	11,40	Texturiser
	Natura-Tec Plantsil™ Xlite	Isoamyl Laurate and Hydrogenated Ethylhexyl Olivatate	22,80	Ultra-light alternative to silicone, degreasing agent
B	Deionized Water	Aqua (Water)	11,40	Solvent
C	Sunobel AVB (Avobenzonone) <i>Nanjing Cosmos Chemical Co.Ltd</i>	Butyl Methoxydibenzoylmethane	5,00	Broad spectrum UV Filter
	Sunobel PA (DHHB) <i>Nanjing Cosmos Chemical Co.Ltd</i>	Diethylamino Hydroxybenzoyl Hexyl Benzoate	10,00	Broad spectrum UV Filter
D	Sunobel OMC (Octinoxate) <i>Nanjing Cosmos Chemical Co.Ltd</i>	Ethylhexyl Methoxycinnamate	7,00	UVB Filter
	Sunobel OS (Octisalate) <i>Nanjing Cosmos Chemical Co.Ltd</i>	Ethylhexyl Salicylate	1,50	UVB Filter
	Sunobel HMS (Homosalate) <i>Nanjing Cosmos Chemical Co.Ltd</i>	Homomenthyl Salicylate	0,50	UVB Filter
E	Natura-Tec SeaBerry Blue™	Triolein (and) Vaccinium Macrocarpon Seed Oil (and) Haematococcus Pluvialis Extract	1,50	Booster of skin natural protection
	Natural Vitamine E	Tocopherol	0,20	Antioxidant
	Geogard ECT	Benzyl Alcohol (and) Salicylic Acid (and) Glycerin (and) Sorbic Acid	0,20	Preservative

PROCEDURE

Heat phase A and phase B up to 75°C. Add phase B to phase A under high shear stirring. Homogenize using Ultra Turax (2min at 7000 rpm) at 80°C. Add phase C. Stop heating and add phase D and E under stirring. Cool immediately in a specific mold.

According BASF simulator : SPF 25 min. (only based on UV filter composition)

APPEARANCE

Pale yellow solid stick

WAY OF USE

Apply the stick directly on the skin.